

SURFACE RESISTANCE CHECKER

The first pocket resistivity Meter, with specifications ranging from 10^3 Ohms per square to 10^{12} Ohms per square, with accuracy $\pm 1/2$ Decade. The meter can be supplied with a certificate of Calibration upon request. The meter measures both surface resistivity and resistance to ground. TO measure surface resistivity, simply place the meter on the material that requires measuring, and press the green test button. The meter will then light the appropriate LED from 10^3 - 10^{12} Ohms per square or insulative. To measure resistance to ground, repeat this process and insert the earth leakage lead in the earth socket attaching the croc clip to your ground point.

The meter uses correctly spaced parallel bars for sensing its measurements and operates with a 9 volt PP3 battery, giving over 40 hours of testing time. Calibration of unit is recommended, this can be obtained by contacting your dealer.

SIZE: 130mm x 70mm x 25mm

POWER: 9voltPP3Battery

EARTHLEAKAGELEAD

PVC CARRYING CASE